

INDASH by PANAVISE®

75107-211

Page 1 of 1

MOUNTING LOCATION:

Right side of radio cavity K R

TOOLS REQUIRED:

Dash Tool, Hook Tool
7mm(9/32) Socket Driver

HARDWARE INCLUDED:

None

CELL PHONE & MEDIA MOUNT
INSTALLATION INSTRUCTIONS

PART#: 75107-211

MFG: FORD

MODELS & YEARS:

Explorer 2011-2018

Police Interceptor SUV 2013-2018

**** ADVISEMENT ****

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1: With hook tool remove the bezel to the right side of the Radio and climate control by inserting hook tool into the lower front corner of the bezel and pull to release (1) clip. Continue up the bezel releasing (3) more clips and (1) plastic lug at the widest part of the bezel. Set aside

STEP #2: Remove the (2) right 7mm(9/32) radio mounting screws: Pull out radio enough to get the InDash by PanaVise Mount behind the lower radio mounting screw. Remove (2) of the 8mm screws. Replace the screws. Make sure the mount is as flush as possible to the dash before tightening.

STEP #4: Carefully replace the bezel starting at the top.

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



Bezel removal (plastic lug)



InDash installed showing location



Mount installed showing screw location



09-21-2020