

INDASH by PANAVISE®

I-75142-306

Page 1 of 1

MOUNTING LOCATION:

Right side of radio cavity KR

TOOLS REQUIRED:

Dash Tool, Hook tool

Phillips screwdriver

HARDWARE INCLUDED:

(1)S7-1876 Mount

CELL PHONE & MEDIA MOUNT INSTALLATION INSTRUCTIONS

PART#: 75142-306

MFG: KENWORTH

MODELS & YEARS:

**T440, T470, C500, T600,
T660, T800, ICON900, W900
(06-22)**

** ADVISEMENT **

Read instructions completely prior to starting installation. All InDash Mounts are designed so that after installation, phone is facing normal driver position for left-hand drive vehicles. This mount is not designed to be used in foreign countries with right-hand drive vehicles. Use extreme care when working around the plastic components on the dash. Excess force, can cause breakage of the plastic components.

STEP #1 With hook tool, remove the bezel that goes from the right of the radio, gauges and switches all the way to the drivers door. There are a total of (13) clips holding this bezel in place.

STEP #2 With Phillips screwdriver remove the upper right screw on center gauge panel. Lift up the gauge panel and slide InDash by PanaVise Mount under panel and over screw hole on upper right of gauges. Replace the screws, making sure the side of the mount is flush with the dash before trying to put the bezel back in place.

STEP #3: Replace the bezel starting from the drivers door side and working to the right side. The InDash by PanaVise Mount should be flush to the dash before the bezel can be installed by the mount.



InDash installed under panel

INSTALLATION IS NOW COMPLETE. ENJOY YOUR NEW INDASH by PANAVISE MOUNT.



InDash installed showing location



06-09-21

There may be recent updates to this Instruction Sheet, please visit our website or contact PanaVise Products, Inc. for the latest revision as well as for the most complete up-to-date PanaVise *InDash Applications List*: 7540 Colbert Dr., Reno, NV, Phone: 800.759.7535, 775.850.2900, Fax: 800.395.8002, www.panavise.com. © 2018 PanaVise Products, Inc.