Technical Data Sheet

Rosenberger

Cable assembly
RPC-3.50 GHz jack / RPC-SL 26.5 GHz jack – RTK 162 VA Armour

LU7-035-XXX



All dimensions are in mm; tolerances: ± 3mm for A ≤ 300 mm; ± 1% for A > 300 mm

Available variants

Type	Insertion loss at max. Frequency	Weight (g) / pce
LU7-035-XXX	≤ 0.00203 dB/mm * A mm + 0.40 dB	0.25 g/mm * A mm + 200 g

XXX – length in mm = A
- Standard lengths are 600, 800 and 1000mm. The smallest possible length is 400mm. -

Note: *max. Insertion Loss:*
First constant = Cable attenuation in dB /mm; Second Constant = Connector left and Connector right +auxiliary Adaptor

Weight:
First constant = Cable- and Armour- weight per mm; Second Constant = Connector left and Connector right weight per pce

Assembly parts

Connector left	RPC-3.50 ruggedized jack	03KR123-2U7S3
Connector right	RPC-SL 26.5 GHz jack	04K123-2U7S3
Cable	RTK 162	
Armour	Metal tubing with fixed bending rate and protection braid	

Electrical data

Impedance	50 Ω
Frequency	DC to 26.5 GHz
Return loss[1]	≥ 26 dB, DC to 4 GHz
	≥ 20 dB, 4 GHz to 26.5 GHz
Insertion loss[1]	see table “Available variants”
RF-leakage	≥ 100 dB up to 1 GHz

[1] Return Loss and Insertion Loss includes the measurement adaptor

Rosenberger Hochfrequenztechnik GmbH & Co. KG
P.O.Box 1260 D-84526 Tittmoning Germany
www.rosenberger.de

Tel. : +49 8684 18-0
Email : info@rosenberger.de

Stability data

Insertion loss stability:

After 90° bending	≤ 0.03 dB, DC to 4 GHz ≤ 0.05 dB, 4 GHz to 26.5 GHz
	≤ 1.0°, DC to 4 GHz ≤ 3.0°, 4 GHz to 26.5 GHz
Straight after 3x90° bending	≤ 0.5°, DC to 4 GHz ≤ 1.5°, 4 GHz to 26.5 GHz

Return loss stability:

After 90° bending	≥ 48 dB, DC to 4 GHz ≥ 40 dB, 4 GHz to 26.5 GHz

Individual testing and documentation:

Stability data is tested according to the specification.
Measurement plot with all 4 S-Parameters (S11; S22; S21; S12) and the care and handling instruction are included with the cable assembly. Auxiliary adaptors used are mentioned in the commentary field.

Mechanical data

Minimum bend radius:	60 mm

Environmental data

Operating temperature range[2]	+20 °C to +26 °C
Rated temperature range of use[3]	0 °C to +50 °C
Storage temperature range	-40 °C to +85 °C
RoHS	compliant

2 Temperature range over which these specification are valid.
3 This range is underneath and above the operating temperature range, within the cable assembly is fully functional and could be used without damage.

Recommended accessories

Wooden case with foam inlay[4] VA_CASE-001

4 Supports two assemblies, for length 600 mm available only.

Rosenberger Hochfrequenztechnik GmbH & Co. KG
P.O.Box 1260 D-84526 Tittmoning Germany
www.rosenberger.de

Tel. : +49 8684 18-0
Email : info@rosenberger.de